

# Handy Store Fixtures Upright Extender Assembly Instructions

## Assembly Instructions:

1. Remove Top Cap Screw.
2. Remove existing Perforated Board.
3. Add the Peforated Board from the Extender Kit, and apply the Perforated Board Divider, attach the Upright Extender.
4. Slide in the piece of existing Perforated Board.

**Please Note:** It's better that there is no seam of the Peforated Board at the point where the Upright Extender meets the existing Upright.

5. Reattach the existing Top Cap with two Top Cap Screws.

