10C Handy Store Fixtures Heavy-Duty

Extender Assembly Instructions

Assembly Instructions:

- 1. Remove the existing Top Cap.
- 2. Remove existing Perforated Board.
- 3. Add the Peforated Board from the Extender Kit and apply the Divider Bar.
- 4. Align the slots of the Upright with the slots of the existing Uprights, slide the key into and thru the slot.

Please Note: A hammer may be required to lock in the Key. The Key should not be able to be removed by hand.

5. Reattach the existing Top Cap with two Top Cap screws.



