

Handy Store Fixtures Wall Unit

Assembly Instructions

Master Parts List:


1. End Upright with End Shoe (#2) bolted to Upright
- 1A. Center Upright with Center Shoe bolted to Upright
2. End Shoe (Base Shelf Rail on one side of Shoe)
- 2A. Center Shoe (Base Shelf Rail on both sides of Shoe)

3. Spacers
4. Back Panel Stop Cap
5. Front Toe
6. Base Shelf
7. *Back Panel

***NOTE:** If unit consists of 3/4"

factory pre-grooved Slatwall, special spacers are required for the Slatwall to fit in Uprights. If not, Slatwall will be 1/4" forward of the Uprights. (ALL DSF SHELVES WILL WORK).

8. Top Cap (remove screws from Uprights and replace)
9. Leveling Screws (shipped in shoe)
10. Plastic Divider Bar (small side out)



Assembly Instructions:

- A) Insert Back Panel Stop Cap (#4) into Uprights. (#1, #1A)
- B) Insert Spacers (#3) into Uprights. (#1, #1A)
- C) Slide Front Toe (#5) into Shoes. (#2, #2A) *See Figure 1A*
- D) **Must secure Wall Unit into Wall using optional Wall Mounting Panel. (furring strip)**
- D1) Wall Units under 96" high requires one Wall Mounting Panel per section and wall units over 96" high requires two Wall Mounting Panels per section.
- E) Slide Back Panel (#7) from top into one Upright, (#1, #1A) then bend and slide into the other Upright. (#1, #1A)
 - * **NOTE:** (If 1/4" Back Panel is more than one piece, place Plastic Divider Bar (#10) between Back Panels. (#7))
- F) Screw Top Cap (#8) into Uprights. (#1, #1A) (screws are shipped in Uprights)
- G) Level the unit horizontally and vertically.
- G1) First level outer leveling screws, then adjust middle leveling screw.
- H) Hook in Base Shelf (#6) and seat properly.

MANUFACTURING STORE FIXTURES SINCE 1952

Handy[®]
STORE FIXTURES

Handy Product Support: (908) 474-1343; Hours of Operation Mon - Fri 8:00 a.m. to 5:00 p.m.

www.handystorefixtures.com